

## Installation Instructions

**FE/E1/E2**

**Replacement Heater Kit**

For the FE Electric Furnace, use the assembly as shipped.

For the E1 or E2 Electric Furnace, cut off the end of the rod extension at the dimple.

St. Louis, MO

**NORDYNE**

707363A (Replaces 7073630)

Specifications and illustrations subject to change without notice and without incurring obligations. Printed in U.S.A. (11/96)

## Installation Instructions

**FE/E1/E2**

**Replacement Heater Kit**

For the FE Electric Furnace, use the assembly as shipped.

For the E1 or E2 Electric Furnace, cut off the end of the rod extension at the dimple.

St. Louis, MO

**NORDYNE**

707363A (Replaces 7073630)

Specifications and illustrations subject to change without notice and without incurring obligations. Printed in U.S.A. (11/96)

## Installation Instructions

**FE/E1/E2**

**Replacement Heater Kit**

For the FE Electric Furnace, use the assembly as shipped.

For the E1 or E2 Electric Furnace, cut off the end of the rod extension at the dimple.

St. Louis, MO

**NORDYNE**

707363A (Replaces 7073630)

Specifications and illustrations subject to change without notice and without incurring obligations. Printed in U.S.A. (11/96)

## Installation Instructions

**FE/E1/E2**

**Replacement Heater Kit**

For the FE Electric Furnace, use the assembly as shipped.

For the E1 or E2 Electric Furnace, cut off the end of the rod extension at the dimple.

St. Louis, MO

**NORDYNE**

707363A (Replaces 7073630)

Specifications and illustrations subject to change without notice and without incurring obligations. Printed in U.S.A. (11/96)