INSTALLATION **INSTRUCTION**

INSTALLATION INSTRUCTIONS FOR MOTORIZED (OAD) OUTSIDE AIR DAMPER 555633

FORM# 655B-0504

I—SHIPPING AND PACKING LIST

Package 1 of 1 contains:

- 1—Damper Section with Motor
- 6—Screws 10 x ½ x 16 Hex Tex

Check contents for shipping damage. Contact the last carrier immediately if any shipping damage is found.


II—APPLICATION

The Outside Air Dampers (OAD) are designed to fit the Return Access Panel. The motorized dampers use a 2-position motor that opens when blower is energized.

III—INSTALLATION

DISCONNECT ALL ELECTRICAL POWER TO THE UNIT **BEFORE SERVICING.**

- 1—Remove fresh air hood and OAD panel from unit.
- 2—Remove OAD slide dampers and set to side for later use.
- 3-Align damper section to mounting holes in OAD panel and secure using screws provided on this kit. See Figure 2.
- 4—Replace OAD slide dampers in desired position.
- 5—Place OAD Panel back in same place unit panel was located. Connect (P1) plug from OAD to (S1) economizer plug on unit.
- 6-Replace fresh air hood over OAD panel and secure using screws removed in Step 1. Seal any corners, clearance holes, etc. to ensure a watertight seal.
- 7—Restore all electrical power to the unit.







Figure 1



NEI35MA10 SEPTEMBER 30, 2004

HARNESS DETAIL

E# = WIRE END DESIGNATION

E2 STUD #6 18 Ga. Wire

E3 Female ¼ Quick Disc. E4 Male ¼ Quick Disc. Insul

E6 Wire Nut Size 73B

HARNESS ENDS AT (P1) FRESH AIR PLUG

COMPONENT CODE

Economizer


M8405A Damper Actuator 24V

P1 OAD Plug

S1 Unit Economizer Plug

WIRE COLOR CODE

BLK Black RED Red



Notes:

1. Unit wiring shown as reference only. Check unit wiring for actual unit wiring.

0-35% Motorized Outside Air Damper for R4GM 150-180 555633

Date: September 30, 2004

Supercedes:

Drawn by:

Unit # 47-287-10

Diagram# 28710W