

# Rheem® FT™ Series & ThermaForce® Boilers Parts List

## Rheem® FT™ SERIES BOILER PARTS

Part No.	Description	RH-BH-FT	RC-BH-FT
P-107A	Sight Glass Kit	✓	✓
P-114B	Fuse Kit (10 Pk)	✓	✓
P-115	Condensate Trap Kit	✓	✓
P-117	Ignitor Gasket - Double ProNG (5 Pk)	✓	✓
P-242C	V-10 Control Board	✓	✓
P-271B	Safety Ignition Module Plus (Sim+) Kit	✓	✓
P-326	Gas Valve Replacement Kit	✓	
P-336	Venturi Insert - 199	✓	
P-338	Venturi Insert Kit	✓	
P-361	Flue Temperature Sensor	✓	✓
P-362	Supply Water Temperature Sensor	✓	✓
P-1011	Water Temperature Sensor	✓	
P-1219	Manual Air Vent	✓	✓
P-1500	Fuel Conversion NG To LP - 110	✓	
P-1502	Fuel Conversion NG To LP - 150	✓	

Part No.	Description	RH-BH-FT	RC-BH-FT
P-1504	Fuel Conversion NG To LP - 199	✓	
P-1507	Exhaust Duct	✓	
P-1508R	Cabinet Front Cover Rheem - FT 110	✓	
P-1511	Ignitor Kit	✓	✓
P-1512	Heat Exchanger Lid - 110	✓	
P-1513	Heat Exchanger Refractory Kit - 110	✓	
P-1517	Water Pressure Sensor	✓	
P-1518	Heat Exchanger Replacement - 110	✓	
P-1519	Burner Kit - 110	✓	
P-1520B	Fan Assembly	✓	
P-1522	Gasket Kit	✓	
P-1524	Heat Exchanger Lid - 150	✓	
P-1525	Heat Exchanger Refractory Kit - 150	✓	✓
P-1526	Burner Kit - 150	✓	✓
P-1528	Heat Exchanger Lid - 199	✓	✓

Part No.	Description	RH-BH-FT	RC-BH-FT
P-1529	Heat Exchanger Refractory Kit - 199	✓	✓
P-1530	Burner Kit - 199	✓	✓
P-1533R	Cabinet Front Cover Rheem - FT 150	✓	
P-1534R	Cabinet Front Cover Rheem - FT 199	✓	
P-1536	Condensate Trap Ret. Clip	✓	
P-1538	Heat Exchanger Service Kit - 110	✓	
P-1539	Heat Exchanger Service Kit - 150	✓	
P-1540	Heat Exchanger Service Kit - 199	✓	
P-1541	Hardware Kit	✓	
P-1542	Install Kit - 110	✓	
P-1543	Install Kit - 150	✓	
P-1544	Install Kit - 199	✓	
P-1545	Pan Gasket Replacement - 110	✓	
P-1546	Pan Gasket Replacement - 150	✓	
P-1547	Pan Gasket Replacement - 199	✓	

Part No.	Description	RH-BH-FT	RC-BH-FT
P-1600	Fuel Conversion NG To LP - 150		✓
P-1602	Fuel Conversion NG To LP - 199		✓
P-1606	Pump & Block Assembly		✓
P-1608	Fan & Coupler Assembly		✓
P-1609	Condensate Pipe		✓
P-1613	Pump Cable		✓
P-1616	CBI Board		✓
P-1617	DHW Water Temperature Sensor		✓
P-1618	DHW Flow Sensor		✓
P-1619	Flow Restrictor/Filter		✓
P-1620	Check Valve		✓
P-1621	Diverter Motor		✓
P-1624	Water Pressure Sensor		✓
P-1625	Gasket Kit		✓
P-1626	Hardware Kit		✓

Part No.	Description	RH-BH-FT	RC-BH-FT
P-1627	Heat Exchanger Lid - 150		✓
P-1630R	Cabinet Front Cover Rheem - FT 150		✓
P-1631R	Cabinet Front Cover Rheem - FT 199		✓
P-1632	Contractor Parts Service Kit		✓
P-1634	Exhaust Duct		✓
P-1636	Combi Block Pump		✓
P-9059	Transformer, 40va/120v-24v	✓	✓
P-9061	Low Water Cutoff Probe, 35mm	✓	✓
P-9070	Manual Reset Switch, 230f	✓	✓
P-9235	Water Pipe Union Gaskets		✓
P-9236	Combi Block Union Gaskets		✓

## Rheem® THERMAFORCE® BOILER PARTS

Part No.	Description	RHBH L99i	RHB L120i	RCB L125i	RCB L160i	RCBH L199i	RTG L199i
P-081164	Backflow Insert	✓	✓	✓	✓	✓	✓
P-081224	Boiler Pump	✓	✓	✓	✓	✓	
P-081314	Boiler Water Pressure Sensor	✓	✓	✓	✓	✓	
P-081154	Burner - 99/120/125	✓	✓	✓			
P-081384	Burner - 160/199				✓	✓	✓
P-082404	Burner Gasket Kit	✓	✓	✓			
P-082414	Burner Gasket Kit				✓	✓	✓
P-081804	Cabinet Temperature Sensor	✓	✓	✓	✓	✓	✓
P-082444	Combustion Gasket Set	✓	✓	✓	✓	✓	✓
P-081304	Condensate Trap - Tankless						✓
P-081654	Condensate Trap - Combi/Boiler	✓	✓	✓	✓	✓	
P-081794	Controller - Thermaforce	✓	✓	✓	✓	✓	✓
P-082424	DHW Bypass Valve / Flow Sensor Turbine				✓	✓	✓
P-081264	DHW Flow Sensor			✓			
P-081444	DHW Flow Sensor (Clip On Only)			✓	✓	✓	✓
P-081814	DHW Strainer			✓	✓	✓	✓
P-081784	DHW Temperature Sensor (15mm)			✓	✓	✓	✓
P-081174	Fan	✓	✓	✓	✓	✓	✓

Part No.	Description	RHBH L99i	RHB L120i	RCB L125i	RCB L160i	RCBH L199i	RTG L199i
P-081134	Flue Temperature Sensor	✓	✓	✓	✓	✓	✓
P-082204	Front Cover Assembly	✓	✓	✓	✓	✓	
P-082214	Front Cover Assembly						✓
P-081924	Front Cover Bolts	✓	✓	✓	✓	✓	✓
P-081234	Gas Valve	✓	✓	✓	✓	✓	✓
P-081354	Gasket Kit	✓	✓	✓			
P-081664	Heat Exchanger DHW Connection Kit			✓			
P-081484	Heat Exchanger Front Panel				✓	✓	✓
P-081854	Heat Exchanger Front Panel	✓	✓	✓			
P-081644	Heat Exchanger Front Panel Bolts	✓	✓	✓	✓	✓	✓
P-082314	Heat Exchanger Mounting Kit	✓	✓	✓	✓	✓	✓
P-081454	Heat Exchanger Service Kit				✓	✓	✓
P-081294	Heat Exchanger Temperature Sensor	✓	✓	✓	✓	✓	✓
P-082454	Hydronic Gasket Set	✓	✓	✓	✓	✓	✓
P-081574	Ignition Control Kit	✓	✓	✓	✓	✓	✓
P-081144	Ignitor Kit	✓	✓	✓	✓	✓	✓
P-081604	Junction Box	✓	✓	✓	✓	✓	
P-081364	Low Calorific Natural Gas Kit	✓					

Part No.	Description	RHBH L99i	RHB L120i	RCB L125i	RCB L160i	RCBH L199i	RTG L199i
P-081374	Low Calorific Natural Gas Kit		✓	✓			
P-081414	Low Calorific Natural Gas Kit					✓	✓
P-081764	Low Calorific Natural Gas Kit				✓		
P-081074	Manual Air Vent	✓	✓	✓			
P-082344	Pressure Relief Valve, 3/4", 30 PSI	✓	✓	✓	✓	✓	
P-081564	Programming Chip (BMM)	✓	✓	✓	✓	✓	✓
P-081014	Propane Conversion Kit						✓
P-081014	Propane Conversion Kit					✓	
P-081034	Propane Conversion Kit	✓					
P-081054	Propane Conversion Kit		✓	✓			
P-081744	Propane Conversion Kit				✓		
P-081914	Pump Fittings	✓	✓	✓	✓	✓	
P-082434	Rear Cabinet Corners	✓	✓	✓	✓	✓	✓
P-080997	Sight Glass	✓	✓	✓	✓	✓	✓
P-081694	Supply Temperature Sensor (22mm)	✓	✓	✓	✓	✓	✓
P-081344	Wall Mounting Kit	✓	✓	✓	✓	✓	✓
P-081614	Wire Connectors X3, X4, X10, X11, X13	✓	✓	✓	✓	✓	✓

## CONTACT US

Customer Service, Warranty and Parts  
800.621.5622

Technical Service  
833.212.9276

Plumber Support  
966.339.2388



Boilers