

Rheem® FT™ Series & ThermaForce® Combi Boilers

Parts List

Rheem® FT™ SERIES COMBI PARTS

Description	RCBH FT150	RCBH FT199
Burner Kit	P-1526	P-1530
Cabinet Front Cover Rheem	P-1630R	P-1631R
CBI Board	P-1616	P-1616
Check Valve	P-1620	P-1620
Combi Block Pump	P-1636	P-1636
Combi Block Union Gaskets	P-9236	P-9236
Condensate Pipe	P-1609	P-1609
Condensate Trap Kit	P-115	P-115
Contractor Parts Service Kit	P-1632	P-1632
DHW Flow Sensor	P-1618	P-1618
DHW Water Temperature Sensor	P-1617	P-1617
Diverter Motor	P-1621	
Exhaust Duct	P-1634	
Fan & Coupler Assembly	P-1608	
Flow Restrictor/Filter	P-1619	
Flue Temperature Sensor	P-361	
Fuel Conversion NG To LP	P-1600	P-1602
Fuse Kit (10 Pk)	P-114B	

Description	RCBH FT150	RCBH FT199
Gasket Kit	P-1625	
Hardware Kit	P-1626	
Heat Exchanger Lid	P-1627	P-1528
Heat Exchanger Refractory Kit	P-1525	P-1529
Ignitor Gasket - Double Prong (5 Pk)	P-117	
Ignitor Kit	P-1511	
Low Water Cutoff Probe, 35mm	P-9061	
Manual Air Vent	P-1219	
Manual Reset Switch, 230f	P-9070	
Pump & Block Assembly	P-1606	
Pump Cable	P-1613	
Safety Ignition Module Plus (Sim+) Kit	P-271B	
Sight Glass Kit	P-107A	
Supply Water Temperature Sensor	P-362	
Transformer, 40va/120v-24v	P-9059	
V-10 Control Board	P-242C	
Water Pipe Union Gaskets	P-9235	
Water Pressure Sensor	P-1624	

Rheem® THERMAFORCE® COMBI PARTS

Description	RCB L125i	RCB L160i	RCBH L199i
Backflow Insert	P-081164	P-081164	P-081164
Boiler Pump	P-081224	P-081224	P-081224
Boiler Water Pressure Sensor	P-081314	P-081314	P-081314
Burner	P-081154	P-081384	P-081384
Burner Gasket Kit	P-082404	P-082414	P-082414
Cabinet Temperature Sensor	P-081804	P-081804	P-081804
Combustion Gasket Set	P-082444	P-082444	P-082444
Condensate Trap	P-081654	P-081654	P-081654
Controller	P-081794	P-081794	P-081794
DHW Bypass Valve / Flow Sensor Turbine		P-082424	P-082424
DHW Flow Sensor	P-081264		
DHW Flow Sensor (Clip On Only)	P-081444	P-081444	P-081444
DHW Strainer	P-081814	P-081814	P-081814
DHW Temperature Sensor (15mm)	P-081784	P-081784	P-081784
Fan	P-081174	P-081174	P-081174
Flue Temperature Sensor	P-081134	P-081134	P-081134
Front Cover Assembly	P-082204	P-082204	P-082204
Front Cover Bolts	P-081924	P-081924	P-081924
Gas Valve	P-081234	P-081234	P-081234
Gasket Kit	P-081354		

Description	RCB L125i	RCB L160i	RCBH L199i
Heat Exchanger DHW Connection Kit	P-081664		
Heat Exchanger Front Panel	P-081854	P-081484	P-081484
Heat Exchanger Front Panel Bolts	P-081644	P-081644	P-081644
Heat Exchanger Mounting Kit	P-082314	P-082314	P-082314
Heat Exchanger Service Kit		P-081454	P-081454
Heat Exchanger Temperature Sensor	P-081294	P-081294	P-081294
Hydronic Gasket Set	P-082454	P-082454	P-082454
Ignition Control Kit	P-081574	P-081574	P-081574
Ignitor Kit	P-081144	P-081144	P-081144
Junction Box	P-081604	P-081604	P-081604
Low Calorific Natural Gas Kit	P-081374	P-081764	P-081414
Manual Air Vent	P-081074		
Pressure Relief Valve, 3/4", 30 PSI	P-082344	P-082344	P-082344
Programming Chip (BMM)	P-081564	P-081564	P-081564
Propane Conversion Kit	P-081054	P-081744	P-081014
Pump Fittings	P-081914	P-081914	P-081914
Rear Cabinet Corners	P-082434	P-082434	P-082434
Sight Glass	P-080997	P-080997	P-080997
Supply Temperature Sensor (22mm)	P-081694	P-081694	P-081694
Wall Mounting Kit	P-081344	P-081344	P-081344
Wire Connectors X3, X4, X10, X11, X13	P-081614	P-081614	P-081614

CONTACT US

Customer Service, Warranty and Parts
800.621.5622

Technical Service
833.212.9276

Plumber Support
966.339.2388



Boilers